

# 1999-2001 ULTRA CAB DROP VISOR INSTRUCTIONS

VERIFY the factory brackets are in the location listed below.  
Remove factory visor and brackets. Drill out factory holes to 1/2"  
Install new brackets in factory locations using supplied hardware.  
Fasten visor skins to brackets using supplied hardware.

35001-IN  
USE WITH 35001  
35001L, 35002

