

VERIFY the factory brackets are in the location listed below.
 Remove factory visor and brackets. Drill out factory holes to 1/2"
 Install new brackets in factory locations using supplied hardware.
 Fasten visor skins to brackets using supplied hardware.

35015-IN
 USE FOR 35015, 35015L
 35016

