

Blind Mount Drop visor for 1995-2005 Ultracab with door mounted mirrors

Ends have nutserts for fastening visor to brackets

Remove factory visor and brackets. Drill out factory holes to 1/2" Install new brackets in factory locations using supplied hardware. Fasten visor skins to brackets using supplied hardware.

