

# 1988-2005 FLAT TOP CAB WITH DOOR MOUNTED MIRRORS REPLACEMENT VISOR INSTRUCTIONS

VERIFY the factory brackets are in the location listed below.  
Remove factory visor and brackets. Drill out factory holes to 1/2"  
Install new brackets in factory locations using supplied hardware.  
Fasten visor skins to brackets using supplied hardware.

35055-IN  
USE FOR 35055, 35055L

4 Brackets included

EXTRA BRACKET IN 9TH  
RIVET LOCATION

9th

6th

2nd

35055-16

35055-18

35055-17

35055-14

-15

-13

ADDITIONAL  
HOLE